

## Single-nozzle Backpack or ATV Sprayer Calibration<sup>1</sup>

B.A. Sellers, J.A. Ferrell, C. R. Rainbolt and G. E. MacDonald<sup>2</sup>

Many growers have isolated patches of weeds that should be controlled to prevent their spread. In this case, spot spraying with a herbicide would be the most economically feasible approach. Some herbicide labels allow for spot-treatments. However, the recommended amount is often given in % volume of herbicide per volume of water, or a certain amount of herbicide per 1,000 square feet.

Before adding any herbicide to the spray tank, it is extremely important that the output of the sprayer is known. That is, it must be properly calibrated. This allows for reduced herbicide costs and optimum weed control. A simple calibration test for a single-nozzle backpack or ATV sprayer is shown in Table 1. No math is required for this calibration and the end result is a known output volume for your sprayer in gallons per acre (GPA).

## Hints for calibration:

- Keep speed constant. This will ensure that you are walking the same speed at all times.
- Keep the nozzle at the same height at all times--a height that is comfortable.

• Modify the wand by adding a pressure gauge. Try to keep the pressure as constant as possible. Do not let the pressure fall below 10 psi.

Next the amount of herbicide to be added to the spray tank needs to be calculated. To do this multiply the amount of herbicide needed for 1 gallon by the number of gallons in the spray tank.

**Example:** A sprayer is calibrated with an output of 40 GPA and the tank holds 10 gallons. If the desired herbicide rate is 1 quart per acre, from Table 2, the amount of herbicide for 1 gallon of water is 4.75 tsp. Since the spray tank holds 10 gallons, 40.75 (41) tsp are needed, which is approximately equal to 7 fl oz.

## **Useful Conversions:**

teaspoon = 0.17 fl oz
tablespoon = 0.5 fl oz
teaspoons = 1 tablespoon
pint = 16 fl oz = 32 tablespoons = 2 cups

The Institute of Food and Agricultural Sciences (IFAS) is an Equal Opportunity Institution authorized to provide research, educational information and other services only to individuals and institutions that function with non-discrimination with respect to race, creed, color, religion, age, disability, sex, sexual orientation, marital status, national origin, political opinions or affiliations. U.S. Department of Agriculture, Cooperative Extension Service, University of Florida, IFAS, Florida A. & M. University Cooperative Extension Program, and Boards of County Commissioners Cooperating. Larry Arrington, Dean

<sup>1.</sup> This document is SS-AGR-108, one of a series of the Agronomy Department, Florida Cooperative Extension Service, Institute of Food and Agricultural Sciences, University of Florida. Original publication date January 2006. Visit the EDIS Web Site at http://edis.ifas.ufl.edu.

B.A. Sellers, assistant professor, Range Cattle Research and Education Center--Ona, FL; J. A. Ferrell, assistant professor, Agronomy Department; C. R. Rainbolt, assistant professor, Everglades Research and Education Center--Belle Glade, FL; and G. E. MacDonald, associate professor, Agronomy Department; Florida Cooperative Extension Service, Institute of Food and Agricultural Sciences, University of Florida, Gainesville, FL 32611.
Use herbicides safely. Read and follow directions on the manufacturer's label.

## Single-nozzle Backpack or ATV Sprayer Calibration

| Step 1 | Measure a calibration plot that is exactly 18.5 feet by 18.5 feet.   |                |                                |
|--------|--|----------------|--------------------------------|
| Step 2 | Spray the calibration plot uniformly with<br>water. Repeat 3 times and record the<br>average number of seconds needed to<br>spray the entire plot. | Time Required  | <br>seconds                    |
| Step 3 | Spray into a clean bucket for the amount of time recorded in Step 2.   |                |                                |
| Step 4 | Measure the number of ounces of water in the bucket.   | Volume Sprayed | <br>Ounces                     |
| Step 5 | The number of ounces collected from<br>the bucket is equal to the number of<br>gallons per acre the sprayer is<br>delivering.                      | Output Volume  | <br>Gallons/Acre               |
| Step 6 | Determine the volume of the spray tank.  | Tank Volume    | <br>gallons                    |
| Step 7 | Determine the amount of herbicide to add to the tank from Table 2.   | Herbicide/Acre | <br>tsp, tbsp, mL, oz,<br>cups |

Table 1. A no-math method for calibrating single-nozzle backpack or ATV wand sprayers for spot spraying herbicides.

Table 2. Amount liquid herbicide to add to 1 gallon of water. Abbreviations: tsp=teaspoon, fl oz=fluid ounces.

| Volume | Recommended Herbicide Rate per Acre |          |            |            |            |  |
|--------|-------------------------------------|----------|------------|------------|------------|--|
| (GPA)  | 1 pint                              | 1 quart  | 2 quarts   | 3 quarts   | 4 quarts   |  |
| 20     | 5 tsp                               | 10 tsp   | 3.25 fl oz | 4.75 fl oz | 6.33 fl oz |  |
| 30     | 3 tsp                               | 6 tsp    | 2 fl oz    | 3.25 fl oz | 4.25 fl oz |  |
| 40     | 2.33 tsp                            | 4.75 tsp | 1.66 fl oz | 2.33 fl oz | 3.25 fl oz |  |
| 50     | 2 tsp                               | 3.75 tsp | 1.25 fl oz | 2 fl oz    | 2.5 fl oz  |  |
| 60     | 1.66 tsp                            | 3.25 tsp | 6.33 tsp   | 1.66 fl oz | 2 fl oz    |  |
| 70     | 1.33 tsp                            | 2.75 tsp | 5.5 tsp    | 1.33 fl oz | 1.75 fl oz |  |
| 80     | 1.25 tsp                            | 2.33 tsp | 4.75 tsp   | 7.25 tsp   | 9.5 tsp    |  |
| 90     | 1 tsp                               | 2 tsp    | 2.25 tsp   | 6.33 tsp   | 8.5 tsp    |  |
| 100    | 1 tsp                               | 2 tsp    | 3.75 tsp   | 5.75 tsp   | 7.66 tsp   |  |